

Project #1. "What causes antibiotic resistance?" Alignment to reference, variant calling

AACCGCGAACTAA

AACCGCTAACGGTAA AACCGCGAACTAA



AAC - GCTAACGGTAA

AACCGCGAAC - - TAA

Course Logistics

One project each 2 weeks - brief introduction, background data and instructions for implementation.


Work in teams of 2.

Report - basically a mini-paper, 2-3 pages long, with introduction, methods, results, etc.


10 points max per project, one lowest score will be dropped.

>70% of the maximum score to pass the course.

Short read alignment



Find the read position in the genome



Alignment

The earliest alignment algorithms (Smith-Waterman and Needleman-Wunsch) are still used today to compare small pieces of DNA one-by-one.

But the computing power needed to map millions of short reads to large genomes requires special algorithms to speed up the process.

Alignment

Burrows-Wheeler transform allows to map reads to the reference sequence.

The reference is summarized with a special reversible index, the index makes its faster to search.

Reads may contain several mutations, insertions, or deletions.

Alignment applications

- Quality assessment
 - Error rate
 - Insert size distribution
 - Chimeric read/read-pairs
 - Genome fraction
- SNP calling
- Comparative analysis
 - CNVs
- Transcriptomics
 - Gene expression
 - Exon/intron detection

Short read alignment


Challenges

Small length
Gigabytes of data
Different sequencing errors
SNPs
Genomic repeats

Tools

Bowtie, BWA (Illumina only)
Bowtie2, BWA-SW, BWA-MEM (Multiple technologies)
TopHat, STAR (RNA-Seq)
...and many more

CNV detection



SAM files

- Read ID (QNAME)
- Reference ID (RNAME)
- Mapping position (POS)
- Mate reference ID (RNEXT)
- Mate position (PNEXT)
- Observed insert length (TLEN)
- Read sequence (SEQ)
- Read quality (QUAL)
- CIGAR string
 - 34M 1I 4M 2D 1X 3M

SAM files

```
@HD
     VN:1.0 SO:coordinate
@SQ
     SN:chr20
                 LN:64444167
@PG
                 VN:2.0.14
                             CL:/srv/dna tools/tophat/tophat -N 3 --read-edit-dist 5 --read-rea
     ID:TopHat
lign-edit-dist 2 -i 50 -I 5000 --max-coverage-intron 5000 -M -o out /data/user446/mapping tophat/index/chr
20 /data/user446/mapping tophat/L6 18 GTGAAA L007 R1 001.fastq
HWI-ST1145:74:C101DACXX:7:1102:4284:73714
                                        chr20
                                              190930 3
                                                          100M
                                                                           0
     AS: i:-15
              XM:i:3 X0:i:0 XG:i:0 MD:Z:55C20C13A9 NM:i:3 NH:i:2 CC:Z:= CP:i:55352714
HWI-ST1145:74:C101DACXX:7:1114:2759:41961
                                              193953 50
                                                          100M
                                        chr20
     TGCTGGATCATCTGGTTAGTGGCTTCTGACTCAGAGGACCTTCGTCCCCTGGGGCAGTGGACCTTCCAGTGATTCCCCCTGACATAAGGGGCATGGACGA
   AS: i:-16
              XM:i:3 X0:i:0 XG:i:0 MD:Z:60G16T18T3 NM:i:3 NH:i:1
HWI-ST1145:74:C101DACXX:7:1204:14760:4030
                                  16
                                        chr20
                                             270877 50
                                                          100M
     DDDDDDDDDCCDDDDDDDDDEEEEEEFFFFFFFGHHHHFGDJJIHJJIJJJIIIIGGFJJIHIIIIJJJJJJJIGHHFAHGFHJHFGGHFFFDD@BB
              XM:i:2 X0:i:0 XG:i:0 MD:Z:0A85G13
                                           NM:i:2 NH:i:1
   AS: i:-11
HWI-ST1145:74:C101DACXX:7:1210:11167:8699
                                              271218 50
                                        chr20
                                                          50M4700N50M
                                                                           0
           GTGGCTCTTCCACAGGAATGTTGAGGATGACATCCATGTCTGGGGTGCACTTGGGTCTCCGAAGCAGAACATCCTCAAAATATGACCTCTCG
accepted hits.sam
```

BAM files


BAM (Binary Alignment Map):

a compressed SAM file, less filesize, not human-readable.

We can convert a sam file to a bam file as follows:

samtools view -S -b alignment.sam > alignment.bam

Alignment visualization with IGV



SNP calling

Process of finding bases in the NGS data that differ from the reference genome

- Typically including an associated statistical confidence score.
- Also known as "variant calling"

We need enough coverage to distinguish real variants from sequencing errors

VCF files

- Chromosome (#CHROM)
- Position (POS)
- Unique identifiers where available (ID)
- Reference base(s) (REF)
- Alternate non-reference alleles (ALT)
- Phred quality score for the variant (QUAL)
- Optional filters (FILTER)
- Additional information (INFO)

VCF files


#CHROM	POS -	ID	REF	ALT	QUAL	FILTER	INFO
1	10177		A	AC	100	PASS	AC=2130; AF=0.425319; AN=5008; NS=2504
1	10235		Т	TA	100	PASS	AC=6;AF=0.00119808;AN=5008;NS=2504
1	10352	rs145072688		T	TA	100	PASS AC=2191;AF=0.4375;AN=5008;NS=2504
1	10505		A	T	100	PASS	AC=1;AF=0.000199681;AN=5008;NS=2504
1	10506		C	G	100	PASS	AC=1;AF=0.000199681;AN=5008;NS=2504
1	10511		G	A	100	PASS	AC=1;AF=0.000199681;AN=5008;NS=2504
1	10539	10.0	C	A	100	PASS	AC=3;AF=0.000599042;AN=5008;NS=2504
1	10542	9.50	C	T	100	PASS	AC=1;AF=0.000199681;AN=5008;NS=2504
1	10579		C	A	100	PASS	AC=1;AF=0.000199681;AN=5008;NS=2504
1	10616	rs376342519		CCGCCGTTGCAAAGGCGCGCCG		GCGCGCCG	C 100 PASS AC=4973;AF=0.993011;AN=5008;NS=2504
1	10642	10.00	G	A	100	PASS	AC=21;AF=0.00419329;AN=5008;NS=2504
1	11008	950	C	G	100	PASS	AC=441;AF=0.0880591;AN=5008;NS=2504
1	11012		C	G	100	PASS	AC=441;AF=0.0880591;AN=5008;NS=2504
1	11063		T	G	100	PASS	AC=15;AF=0.00299521;AN=5008;NS=2504
1	13011		T	G	100	PASS	AC=3;AF=0.000599042;AN=5008;NS=2504
1	13110		G	A	100	PASS	AC=134;AF=0.0267572;AN=5008;NS=2504

VCF file structure


```
##fileformat=VCFv4.1
##fileDate=20090805
##tcgaversion=1.1
##vofProcessLog=<InputVCF=<file1.vcf>,InputVCFSource=<caller1>,InputVCFVer=<1.0>,InputVCFParam=<a1,b>,InputVCFqeneAnno=<anno1.qaf>>
##reference=ftp://ftp.ncbi.nih.gov/genbank/genomes/Eukaryotes/vertebrates_mammals/Homo_sapiens/GRCh37/special_requests/GRCh37-lite.fa
##contig=<ID=20,length=62435964,assembly=B36,md5=f126cdf8a6e0c7f379d618ff66beb2da.species="Homo sapiens",taxonomy=x>
##phasing=partial
##INFO=<ID=NS, Number=1.Type=Integer, Description="Number of Samples With Data">
##INFO=<ID=DP, Number=1, Type=Integer, Description="Total Depth">
##INFO=<ID=AF, Number=A, Type=Float, Description="Allele Frequency">
                                                                                INFO meta-information
##INFO=<ID=AA Number=1 Type=String Description="Ancestral Allele">
##INFO=<ID=DB, Number=0, Type=Flag, Description="dbSNP membership, build 129">
##INFO=<ID=H2 Number=0 Type=Flag Description="HapMap2 membership">
##FILTER=<ID=g10.Description="Ouality below 10">
                                                                                FILTER meta-information
##FILTER=<ID=$50.Description="Less than 50% of samples have data">
##FORMAT=<ID=GT.Number=1.Type=String.Description="Genotype">
##FORMAT = < ID = GQ, Number = 1, Type = Integer, Description = "Genotype Quality" >
                                                                                 FORMAT meta-information
##FORMAT = < ID=DP. Number=1. Type=Integer. Description="Read Depth">
##FORMAT=<ID=HO.Number=2.Type=Integer.Description="Haplotype Quality">
##SAMPLE=<ID=NORMAL,Individual=TCGA-01-1000,File=TCGA-01-1000-1.bam,Platform=Illumina,Source=dbGAP,Accession=1234>
##SAMPLE=<ID=TUMOR.Individual=TCGA-01-1000.File=TCGA-01-1000-2.bam.Platform=Illumina.Source=dbGAP.Accession=4567>
##PEDIGREE=<Name 0=TUMOR,Name 1=NORMAL>
                                                                              Optional: FORMAT field specifying data type
                                                                                      + Per-sample genotype data
                      Fixed fields
#CHROM POS
                                         OUAL FILTER INFO
                                                                                  FORMAT
                                 ALT
                                                                                               NORMAT.
               rs6054257 G
       14370
                                              PASS
                                                     NS=3:DP=14:AF=0.5:DB:H2
                                                                                   GT:GO:DP:HO 0 0 0:48:1:51.51 1 0:48:8:51.51
                                                                                   GT:GQ:DP:HQ 0 0:49:3:58,50 0 1:3:5:65,3
       17330
                                                     NS=3:DP=11:AF=0.017
                                              q10
       1110696 rs6040355 A
                                              PASS
                                                     NS=2:DP=10:AF=0.333.0.667:DB GT:GO:DP:HO 1 2:21:6:23.27 2 1:2:0:18.2
20
       1230237
                                              PASS
                                                     NS=3; DP=13; AA=T
                                                                                   GT:GQ:DP:HQ 0 0:54:7:56,60 0 0:48:4:51,51
20
       1234567 microsat1 GTC
                                 G.GTCTC 50
                                              PASS
                                                     NS=3:DP=9:AA=G
                                                                                   GT:GO:DP
                                                                                               0/1:35:4
```

VCF file structure


Example



Alignment visualization with IGV: one sample



Alignment visualization with IGV: multiple samples



Tools

- Alignment and data processing
 - o samtools
 - vcftools
- SNP calling and annotation
 - VarScan
 - SnpEff
- Visualization
 - Tablet
 - IGV
- Pipelines
 - GATK


Real sequencing data from a strain of *E. coli* resistant to the antibiotic ampicillin.




Goals


- Map reads to reference
- Locate mutations
- Figure out what mutations do
- Classify mechanism of resistance
- Make recommendations for alternative treatment

Ampicillin acts as an irreversible inhibitor of the enzyme transpeptidase, which is needed by bacteria to make the cell wall.





Ampicillin acts as an irreversible inhibitor of the enzyme transpeptidase, which is needed by bacteria to make the cell wall.

















General mechanisms of resistance

- 1) target site alteration so antibiotic can't bind
- 2) inactivation or modification of antibiotic itself
- 3) alter metabolic pathway to compensate
- 4) reduce amount of drug in cell
- 4b) kick drug out of the cell (efflux pumps)
 - 4a) decrease permeability so drug can't enter (alter pores to block hydrophilic drugs, alter membrane to block hydrophobic drugs)

General mechanisms of resistance

Which one works in our case?

(and what can we do?)

Thank you!

Questions?